

SECTION – REMOVAL Q / M-24

SCALE IN FEET 0 8 16



SECTION – INSTALLATION Q / M-25

SCALE IN FEET 0 8 16



SECTION – REMOVAL R / M-24

SCALE IN FEET 0 8 16



SECTION – INSTALLATION R / M-25

SCALE IN FEET 0 8 16